



## VST Outputs - Main Mix

In order for the Control Room to function correctly, the Main Mix in the VST Outputs tab must be assigned to the set of outputs that actually contains your final mix signal. If you only have one VST Output Bus, it will be the Main Mix by default. If you have more than one VST Output Bus defined, you can change which one is the Main Mix by right-clicking (Win) or [Ctrl]-clicking (Mac) on the name of the VST Output and selecting “Set “Out” as Main Mix”.



The Main Mix is marked by a small orange speaker icon to the left of its name.



VST Outputs other than the Main Mix are not routed through the Control Room Mixer. They can, however, share the Device Ports of Studio and Monitor channels in the Control Room.